# Service and Repair Instructions

# Vertex Fasteners Pneumatic Stapler Type

This Spare parts list/service instructions and the enclosed Operator's Manual constitute the Operating Instructions. Before using read both and strictly observe safety instructions.

Attention! Always disconnect the tool from its air supply and empty magazine before attempting any repair. Always tighten the cap with a torque wrench adjusted to 7

### Removing piston and driver blade

Take out 4 cap screws VC7378 and remove the complete cap and valve shaft assembly (fig. 1). The piston with driver blade can now be removed by using a spare driver blade and pushing them from below (fig. 2). Use a pin punch for removing the pin VC7027 and split pin VC7337 (fig. 3). Any damaged parts must be replaced. Before refitting, the piston O-ring should be greased.

#### Changing of bumper and cylinder


Take off cap screws VC7371, VC7373, and VC7379 now remove magazine. Take out piston-driver assembly and bumper. Gently tap the housing on a wooden surface. By the impact, the cylinder will come out and can easily be removed from the housing. Replace the damaged  $% \left( \mathbf{r}\right) =\mathbf{r}^{\prime }$ parts and grease before refitting (fig. 4).


#### Replacement of the pusher and roller spring


Pull back the pusher enough to expose the front roller spring attachment and e-ring retainer. Remove e-ring retainer and undo front of spring. Remove the e-ring retainer from the pusher stop. Remove pusher stop, and spring. Slide the pusher off the back of the staple carrier and remove the spring. Replace any worn or defective parts. Reconnect the spring in the front and re-install the e-ring retainer. With the spring in the pusher guide the spring along the carrier to the end and re-install the pusher over the carrier. Re-install the pusher stop, spring, and e-ring retainer


# Changing of O-rings in head valve assembly

Remove the cap as described above. Take main valve out of the cap and replace worn 0-rings. Grease O-rings before refitting.

















# **Tool Parts**

Vertex Fasteners Pneumatic Stapler Type VA0266

| Vertex Fasteners Pneumatic Stapler Type VA0266 |             |                          |          |  |
|--|-------------|--------------------------|----------|--|
| Call-out #                                     | Part Number | Description              | Quantity |  |
|  |             |                          |          |  |
| 1  | VC7276      | O-ring                   |          |  |
| 2  | VC7278      | O-ring                   |          |  |
| 3  | VC7306      | O-ring                   |          |  |
| 4  | VC7293      | O-ring                   |          |  |
| 5  | VC7295      | O-ring                   |          |  |
| 6  | VC7314      | O-ring                   |          |  |
| 7  | VC7319      | O-ring                   |          |  |
| 8  | VC7320      | O-ring                   |          |  |
| 9  | VC7321      | O-ring                   |          |  |
| 10   | VC7322      | O-ring                   |          |  |
| 11   | VC7324      | O-ring                   |          |  |
| 12   | VC7327      | Seal                     |          |  |
| 13   | VC7331      | Pin                      |          |  |
| 14   | VC7337      | Split pin                |          |  |
| 15   | VC7341      | E-ring retainer          |          |  |
| 16   | VC7343      | Retainer                 |          |  |
| 17   | VC7369      | Socket head cap screw    |          |  |
| 18   | VC7371      | Socket head cap screw    |          |  |
| 19   | VC7376      | Socket head cap screw    |          |  |
| 20   | VC7378      | Socket head cap screw    |          |  |
| 21   | VC7379      | Socket head cap screw    |          |  |
| 22   | VC7345      | Lock washer              |          |  |
| 23   | VC7373      | Button head socket screw |          |  |
| 24   | VC7386      | Hex nut                  |          |  |
| 25   | VC7000      | Button head socket screw |          |  |
| 28   | VC7000      | Pin                      |          |  |
| 29   | VC7027      | Reducer bushing          |          |  |
| 30   |             |                          |          |  |
|  | VC7029      | Piston                   |          |  |
| 31   | VC7193      | Pressure Spring          |          |  |
| 32   | VC7032      | Pressure Spring          |          |  |
| 33   | VC7054      | Valve Spring             |          |  |
| 34   | VC7031      | Spring Stop              |          |  |
| 35   | VC7051      | Perforated plate         |          |  |
| 36   | VC7166      | Perforated plate         |          |  |
| 37   | VC7052      | Muffler                  |          |  |
| 38   | VC7053      | Cap insert               |          |  |
| 39   | VC7155      | Trigger                  |          |  |
| 41   | VC7387      | Roller spring            |          |  |
| 42   | VC7186      | Carrier cover            |          |  |
| 43   | VC7017      | Pusher                   |          |  |
| 44   | VC7191      | Spring Retainer          |          |  |
| 45   | VC7160      | Bumper                   |          |  |
| 46   | VC7161      | Cylinder                 |          |  |
| 47   | VC7162      | Trip yoke                |          |  |
| 48   | VC7163      | Nose plate               |          |  |
| 49   | VC7164      | Driver blade             |          |  |
| 50   | VC7165      | Gasket                   |          |  |
| 51   | VC7167      | Сар                      |          |  |
| 52   | VC7168      | Exhaust valve            |          |  |

| Call-out # | Part Number | Description    | Quantity |
|------------|-------------|----------------|----------|
|            |             |                |          |
| 53         | VC7169      | Main valve     |          |
| 54         | VC7172      | Valve bush     |          |
| 55         | VC7184      | Driver guide   |          |
| 56         | VC7006      | Hook plate     |          |
| 57         | VC7007      | Plate          |          |
| 58         | VC7004      | Body           |          |
| 59         | VC7005      | Nose           |          |
| 60         | VC7010      | Back plate     |          |
| 61         | VC7009      | Staple carrier |          |
| 62         | VC7008      | Pusher stop    |          |
| 63         | VC7003      | Valve shaft    |          |
| 64         | VC7187      | Bushing        |          |
| 65         | VC7188      | Pin            |          |
| 66         | VC7189      | Leg spring     |          |

